



# CSR1 & CSR2-B & E SERIES

CSR1/2-B/E  
X10282

## INTRODUCTION

The CSR power regulators are compact and robust units, which are capable of controlling single-phase mains driven loads of up to 15A. The CSR2 series regulators come in two styles, open (type B) and enclosed (type E), with the enclosed version having its own heatsink. The regulator gives a fully adjustable output from zero to maximum voltage. The standard unit is rated for 110V and 230V ac, but other voltages are available on request.

## APPLICATIONS

Suitable for conventional resistive heating elements such as ovens, quartz lamps, moulders and dryers. Also suitable for some inductive loads such as transformers, fans and motors.

## FEATURES

- Available in 6, 10, and 15A ratings.
- Compact and easy to use.
- Simple installation - with or without heatsink.
- Discrete component giving high reliability.
- Cost effective.







EXAMPLE - CSR2-15E





## INSTALLATIONS

## DIMENSIONS AND CONNECTIONS

CSR2 B SERIES



CSR2 E SERIES



### WARNING

LIVE TERMINALS - SWITCH OFF SUPPLY BEFORE COMMENCING ANY SERVICE WORK.

### MOUNTING INSTRUCTIONS


DRILL A 10.3mm HOLE  
WHEN FIXING CSR TO ADDITIONAL HEATSINK, A SMEAR OF HEATSINK COMPOUND SHOULD BE USED BETWEEN THE BONDED SURFACES TO AID THERMAL COUPLING  
EARTH BONDING SHOULD BE ACHIEVED BETWEEN ALL MATING SURFACES

## INSTALLATIONS

## COOLING REQUIREMENTS

## Heatsink rating v rms maximum current

Stainless steel typically 15 times less thermally conductive and mild steel which is typically 5 times less thermally conductive.



## SPECIFICATIONS

### UNIT TYPE

### CSR1 (110V) & CSR2 (230V)

|   |                  | 6B    | 6E   | 10B             | 10E   | 15B  | 15E  |
|---|------------------|-------|------|-----------------|-------|------|------|
| Maximum on-state current, I <sub>max</sub> (tab @ 70°C) | A rms            | 6     | 6    | 10              | 10    | 15   | 15   |
| Peak one cycle surge currents                           | A                | 100   | 100  | 120             | 120   | 150  | 150  |
| Off - leakage current (maximum)                         | mA               | ----- |      | 2               | ----- |      |      |
| Minimum holding load current                            | mA               | ----- |      | 30              | ----- |      |      |
| RMS input voltage +/- 10% @ 50/60 Hz                    | V                | ----- |      | 110 or 230      | ----- |      |      |
| Repetitive peak voltage (tab @ 70°C)                    | V                | ----- |      | 400             | ----- |      |      |
| Hysteresis  | %                | ----- |      | 5               | ----- |      |      |
| Total conduction phase angle (typical)                  | degrees          | ----- |      | 0 to 160°       | ----- |      |      |
| Controlled phase angle (typical)                        | degrees          | ----- |      | 30 to 160°      | ----- |      |      |
| Power transfer at I <sub>max</sub> (efficiency)         | %                | ----- |      | 99              | ----- |      |      |
| Tab surface operating range                             | °C               | ----- |      | 0 to + 75       | ----- |      |      |
| Storage temperature                                     | °C               | ----- |      | 0 to + 75       | ----- |      |      |
| Insulation withstand capability (tab @ 70°C)            | V                | ----- |      | 1500 for 1 min. | ----- |      |      |
| I <sup>2</sup> t limiting values for fusing             | A <sup>2</sup> s | 18    | 18   | 50              | 50    | 100  | 100  |
| Mounting hole diameter (minimum)                        | mm               | 10.3  | 10.3 | 10.3            | 10.3  | 10.3 | 10.3 |

**NOTE:** For supply voltages above 120V or 240V  
AC the controller may not turn off fully.

## FUSING

It is recommended to use semiconductor (fast acting) type fuses or circuit breakers (semiconductor- MCB) for unit protection. On initial 'switch on' some loads may need an increased Factor of Safety (F of S) for unit and/or device protection. See SRA Data sheet for further information.

## CE MARKING

This product family carries a "CE marking". These phase angle controllers need a suitable remote filter. For more information see *recommendations* section and contact our sales desk.

## RECOMMENDATIONS

Other documents available on request, which may be appropriate for your applications:-

| CODE   | IDENTITY | DESCRIPTION   |
|--------|----------|---|
| X10229 | RFI      | Filtering recommendation - addressing EMC Directive.  |
| X10213 | ITA      | Interaction, uses for phase angle and for burst fire control.   |
| X10255 | SRA      | Safety requirements - addressing the Low Voltage Directive (LVD) including :-<br>Thermal data/cooling ; "Live" parts warning & Earth requirements; Fusing<br>recommendations. |
| X10378 | ILR      | Inductive loads remedy sheet for use with Phase Angle Controllers   |
| P01.1  | COS      | UAL Conditions of sale.   |

**NOTE:** It is recommended that installation and maintenance of this equipment should be done with reference to the current edition of the I.E.T. (formally I.E.E.) regulations (BS7671) by suitably qualified/trained personnel. The regulations contain important requirements regarding installation and safety of electrical equipment. Specific installers should refer to local and national regulations.

**ORDER CODE:** State part number: **CSR1 or 2** (Denotes supply voltage) + (current rating) + type 'B' or 'E'  
Optional extras include: knob, dial, heatsink compound, filters.  
*Note: When ordering a filter, the current the CSR is to be used at will be required.*